

**(3) SIZE 5, (3) SIZE 3, (1) SIZE 2, (13) SIZE 1, (4) SIZE 0,  
FURNAS MOTOR CONTROL CENTER (MCC)**

**VERTICAL SECTION #1 – 2 HIGH**

COMPARTMENT #1

15 AMP FUSED DISCONNECT

COMPARTMENT #2

SIZE 5 FVNR STARTER- WESTINGHOUSE 400 AMP MCB LBB3400NW  
FURNAS SIZE 5, CONTACTOR, (3) CT'S 300:5

**VERTICAL SECTION #2 - 2 HIGH**

COMPARTMENT #1

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR

COMPARTMENT #2

SIZE 5 FVNR SRARTER – WESTINGHOUSE 400 AMP MCB LBB3400NW:  
FURNAS SIZE 5 CONTACTOR (3) CTO 30085

**VERTICAL SECTION #3 –HIGH**

COMPARTMENT #1

SIZE 1 FVNR STARTER – 14DF32AA81A CONTACTOR, 15 AMP FUSES

COMPARTMENT #2

SIZE 5 FVNR STARTER – 400 AMP FUSED DISCONNECT, FURNAS SIZE 5  
CONTACTOR, (3) CT'S 300:5

**VERTICAL SECTION #4 – 4 HIGH**

COMPARTMENT #1

EMPTY

COMPARTMENT #2

SIZE 1 FVNR STARTER – 14DF32AA81A CONTACTOR, 20 AMP FUSES

COMPARTMENT #3

SIZE 1 FVNR STARTER – 14DF32AA81A CONTACTOR, 20 AMP FUSES

COMPARTMENT #4

SIZE 1 FVNR STARTER – 14DF32AA81A CONTACTOR, 20 AMP FUSES

**VERTICAL SECTION #5 –5 HIGH**

COMPARTMENT #1

SIZE 2 FVNR STARTER, 60 AMP FUSES

COMPARTMENT #2

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR, 20 AMP FUSES

COMPARTMENT #3

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR, 20 AMP FUSES

COMPARTMENT #4

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR, 8 AMP FUSES

COMPARTMENT #5

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR, 3.2 AMP FUSES

**VERTICAL SECTION #6 – 5 HIGH**

COMPARTMENT #1

EMPTY

COMPARTMENT #2

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR

COMPARTMENT #3

SIZE 1 FVNR STARTER – FURNAS 14DF32AA81A CONTACTOR

COMPARTMENT #4

20 AMP FUSED DISCONNECT

COMPARTMENT #5

25 AMP FUSED DISCONNECT

**VERTICAL SECTION #7 – 6 HIGH**

COMPARTMENT #1

SIZE 0 FVNR STARTER, WESTINGHOUSE 15 AMP MCP, CAT # MCP03150R,  
FURNAS 14CF32AA71A

COMPARTMENT #2

SIZE 0 FVNR STARTER, WESTINGHOUSE 15 AMP MCP, CAT # MCP03150R,  
FURNAS 14CF32AA71A

COMPARTMENT #3

SIZE 0 FVNR STARTER, WESTINGHOUSE 15 AMP MCP, CAT # MCP03150R,  
FURNAS 14CF32AA71A

COMPARTMENT #4

SIZE 0 FVNR STARTER, WESTINGHOUSE 15 AMP MCP, CAT # MCP03150R,  
FURNAS 14CF32AA71A

COMPARTMENT #5

SIZE 1 FVNR STARTER – WESTINGHOUSE 30 AMP MCP CAT # 11300R

COMPARTMENT #6

SIZE 1 FVNR STARTER – WESTINGHOUSE 30 AMP MCP CAT # 11300R

**VERTICAL SECTION #8 – 4 HIGH**

COMPARTMENT #1

100 AMP FUSED DISCONNECT

COMPARTMENT #2

SIZE 3 FVNR STARTER – CUTLER HAMMER 50 AMP HMCP CAT I#  
HMCP050K2C, ESP-100 SOLID STATE OVERLOAD, FURNAS 14HST32AA  
CONTACTOR

COMPARTMENT #3

SIZE 3 FVNR STARTER – CUTLER HAMMER 50 AMP HMCP CAT I#  
HMCP050K2C, ESP-100 SOLID STATE OVERLOAD, FURNAS 14HST32AA  
CONTACTOR

COMPARTMENT #4

SIZE 3 FVNR STARTER – CUTLER HAMMER 50 AMP HMCP CAT I#  
HMCP050K2C, ESP-100 SOLID STATE OVERLOAD, FURNAS 14HST32AA  
CONTACTOR

90”H X 160”W X 21”D

**INVENTORY ID: 113118-007-02**

**CASEY**

*275 Kappa Drive, Pittsburgh, PA 15238*

*Ph: (800) 882-7000 · (412) 963-1111*

*Fax: (412) 963-0808 Web: [www.caseyusa.com](http://www.caseyusa.com)*