

(2) SIZE 4, (3) SIZE 3, (12) SIZE 1, FURNAS SYSTEM 89, MOTOR CONTROL CENTER (MCC)

VERTICAL SECTION #1 - 5 HIGH

COMPARTMENT #1
INCOMING

COMPARTMENT #2
50 A FUSED DISCONNECT SWITCH, SIZE 1 FVNR STARTER

COMPARTMENT #3
10 AMP DISCONNECT SWITCH, SIZE 2 FVNR STARTE

COMPARTMENT #5
EMPTY

VERTICAL SECTION #2 - 5 HIGH

COMPARTMENT # 1
5.5 AMP FUSED DISCONNECT
SIZE 1 FVNR STARTER

COMPARTMENT #2
5 AMP FUSED DISCONNECT
SIZE 1 FVNR STARTER

COMPARTMENT #3
50 AMP FUSED DISCONNECT
SIZE 3 FVNR STARTER

COMPARTMENT #4
15 AMP FUSED DISCONNECT
SIZE 1 FVNR STARTER

COMPARTMENT #5
EMPTY

VERTICAL SECTION #3 - 5 HIGH

COMPARTMENT #1
30 AMP FUSED DISCONNECT
SIZE 1 FVNR STARTER

COMPARTMENT #2

CASEY

5.5 AMP FUSED DISCONNECT
SIZE 1 VFNR STARTER

COMPARTMENT #3
50 AMP FUSED DISCONNECT
SIZE 3 FVNR STARTER

COMPARTMENT #4
20 AMP FUSED DISCONNECT
SIZE 2 FVNR STARTER

COMPARTMENT #5
EMPTY

VERTICAL SECTION #4 - 5 HIGH

COMPARTMENT #1
SIZE 1 VFNR STARTER

COMPARTMENT #2
EMPTY

COMPARTMENT #3
(2) 50 AMP FUSED DISCONNECTS

COMPARTMENT #4
(2) 30 AMP FUSED DISCONNECTS

COMPARTMENT #5
EMPTY

VERTICAL SECTION #5 - 4 HIGH

COMPARTMENT #1
SIZE 1 VFNR STARTER

COMPARTMENT #2
EMPTY

COMPARTMENT #3
60 AMP FUSED DISCONNECT

COMPARTMENT #4
EMPTY

VERTICAL SECTION #6 - 5 HIGH

COMPARTMENT #1
20 AMP FUSED DISCONNECT, SIZE 1 FVNR STARTER

COMPARTMENT #2

CASEY

30 AMP FUSED DISCONNECT, SIZE 1 FVNR STARTER

COMPARTMENT #3

5.5 AMP FUSED DISCONNECT, SIZE 1 FVNR STARTER

COMPARTMENT #4

80 AMP FUSED DISCONNECT

COMPARTMENT #5

EMPTY

VERTICAL SECTION #7 - 1 HIGH

COMPARTMENT #1

125 AMP FUSED DISCONNECT, SIZE 4 60/15 HP REVERSING STARTER
(2) ADDITIONAL SIZE 4 AND (2) SIZE 2 REVERSING CONTACTORS

VERTICAL SECTION #8 - 1 HIGH

COMPARTMENT #1

125 AMP FUSED DISCONNECT, SIZE 4 60/15 HP REVERSING STARTER
(2) ADDITIONAL SIZE 4 AND (2) SIZE 2 REVERSING CONTACTORS

INVENTORY ID: 113122-000-00

CASEY

www.caseyusa.com

275 Kappa Drive, Pittsburgh, PA 15209 • Phone: (412) 963-1111 Fax: (412) 963-0808 •